

Git'Um Fed™ Automated Animal Feeder

Wall Mounting Instructions

For Wall Bracket Kit # 7570WB

1. Purpose: Provides a permanent mounting on a vertical surface such a fence, wall of a building or stable or other suitable vertical surface. Increases stability when using optional extension housings (part # 7560EH) to increase the quantity of food available for dispensing.
2. Instructions: Included in the Wall Mounting Kit are two metal brackets. These will replace the Legs on the Feeder.
 - A. Disassemble the feeder:
 1. If the feeder is in use, unplug it from the power source. Empty and store the food.
 2. Remove the lid
 3. Remove the Trough halves from the bottom of the Feeder Housing (It is not necessary to remove the Motor or the Auger Assembly for this conversion)
 6. Remove the 4 attaching screws and remove the legs.
 - B. Attach the Bracket to the Feeder:
 1. Locate the two brackets and the mounting hardware bag in the Wall Mounting Kit.
 2. Position the longer side of the bracket on bottom of the Feeder Housing from the Spout side to the Motor side. The smaller side of the bracket should be pointing downward on the Motor side of the Housing.
 3. Match the holes in the bracket with those in the bottom of the Feeder Housing.
 4. Insert each of the 4 included longer screws through the large washers provided.
 5. Insert these down through the holes in the bottom of the Feeder Housing and through the matching holes in the bracket.
 6. Install the washers and nuts used to attach the legs. Tighten the screws
 7. Re-assemble the Feeder
 - C. Wall mounting:
 1. Determine a suitable location for mounting the Feeder
 2. Use fasteners suitable for the type of mounting you have chosen that will support the weight of the Bracket/Feeder Assembly



